

Spike Marker – End-Cap Kit Instruction

Fitting

Prepare the end of the microduct for insertion (cut square and deburr).



Push the prepared end of the microduct into the open end of the coupler that Tempo has attached to the SM25.



Removal

To remove the end-cap marker assembly from the microduct: First clean the marker, coupler and microduct to reduce the risk of contamination. Next, remove the security clip (if used) and retract the retention ring to release the coupler.

Reuse

SM25KT can be re-used. Just keep it clean.

Do you like this solution?
Please contact Heynen for distribution in BENELUX.